Welcome to Thermacell

You're ready to discover a better way to repel mosquitoes. Thermacell products create a zone of protection from mosquitoes, without the use of messy sprays or lotions. Thermacell patented technology uses heat to release repellent continuously, providing hours of protection.

Turn it on and within 15 minutes you will be protected from mosquitoes in the surrounding area. Up to a 6m diameter.



In the Box

- 1 Thermacell EX90 Repeller
- 1 Thermacell Repellent 40 Hour Refill cartridge
- 1 USB Cable



1. Let's get started

Your THMREX90 device has a rechargeable battery. Fully charge the repeller before first use. To charge the battery pull away charge port cover to expose the USB charging port located on the front of the device. Insert the USB cable provided with the device. The battery indicator is located below the power button.

Device Status





Battery Too Low to Operate.

Battery Indicator





Charging.

Fully Charged.

2. Inserting a Refill

- · Remove top from the device: To remove the top, grasp both sides of your THMREX90 pushing in both buttons with one hand and remove the top with the other.
- Remove the cap from a cartridge.
- Insert the cartridge into the repeller.
- Replace the THMREX90 device top taking care not to damage the Refill wick. The device uses magnets to hold the top to the bottom of the device.



on the side of the repeller.





is fully on.

Use only with Thermacell Repellent Refills

3. Using the repeller

- Press the power button to turn ON.
- · Light will illuminate when turned on.
- Place the repeller in center of area where mosquito protection is desired and run the repeller for 15 minutes to establish the protection zone.
- The cartridge will last 40 hours.
- Only use outdoors. Do not cover. Keep repeller upright during use.
- To turn off, press the power button for 1 second until the light turns off.







Moving Illumination: Unit is warming up



Solid Illumination: Unit is actively releasing repellent

Useful Tips

- · For best results, place in the center of the area you want to protect from mosquitoes.
- · Allow 15 minutes for the full protection zone to be established.
- · For optimal protection in larger areas, use multiple repellers spaced 3-4 metres apart.
- · Effectiveness can be impacted by wind and air movement. Place upwind on a windy day.
- Avoid exposing open refills or device to rain.
- The refill wick will get hot while in use. Always allow to cool before
- · Do not attempt to touch, break, or remove the refill wick.
- · Only use Thermacell Zone refills in this device.



Maintenance

- Condensation can build up on and around the top over time. Turn repeller off and wipe with a damp cloth. Do not use chemicals or
- Replace cap on cartridge and store in a dry place when not using the repeller.
- Partially used cartridges should be removed from the device and capped or disposed of prior to storing for extended periods of
- Do not leave repeller outside when not in use. Store in a cool dry

Batteries should be charged at least once every 3 months during storage.

Troubleshooting

- 1. If the repeller won't turn on:
- Check that the top of the repeller is properly seated on the base. The repeller will not operate if top and bottom are separated.
- Charge the battery. The repeller will not turn on if battery is too low.
- 2. If you are still bothered by mosquitoes after 15 minutes:
- · Check that the device is on. Light ring should be illuminated.
- · Confirm a cartridge is inserted and cartridge has repellent.
- Make sure the wick is not damaged or missing.
- Be sure the repeller is within 3-4 metres from you.
- Allow the device to run for up to 15 minutes.
- Call or email customer service if you still experience problems using your repeller. (customerservice@mayohardware.com.au)

Thermacell Repellents, Inc. 32 Crosby Dr Suite #100 Bedford MA 01730 USA

DISTRIBUTED BY Mavo Hardware Ptv Ltd 4 Secombe Place Moorebank NSW 2170 Customer Service: 1300 360 211 www.thermacellrepellents.com.au

Mayo Hardware will honour all statutory quarantees that this product is of acceptable quality. (including that it is fit for purpose).



IMPORTANT: **READ ALL INSTRUCTIONS BEFORE USE**

ATTENTION: This product is intended for adult use only. This product is not a toy. IMPORTANT SAFETY INFORMATION. READ CAREFULLY BEFORE USE.

NOTICE: This product contains a lithium ion battery which is subject to certain transport restrictions. Inspect the product's packaging prior to transport. Do not transport this product if the component housing the battery is

When using rechargeable battery operated products, basic precautions should always be taken.

To reduce the risk of injury, close supervision is necessary when a product is used near children.

KEEP OUT OF REACH OF CHILDREN

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

DO NOT put fingers, hands, metal or other foreign objects in the product. Do not remove the battery from the

equipment housing. Do not store with battery completely discharged for extended periods of time. Batteries should be charged at least once every 3 months during storage. Battery should be discharged and charged after being stored more than a year to maintain optimal battery capacity. The battery should be stored at room temperature in a dry location and should not be placed, charged or stored in high-temperature locations. Exposure of the battery or device to fire or temperature above 130°C/265°F may cause explosion.

Charging should be performed at a temperature between 40 °F (5°C) and 110 °F (40°C). Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire. Recharge only with a USB Listed/Certified Class 2 Power unit charger marked 5V DC-1000 mA, do not exceed 5V DC. This appliance contains batteries that are non-replaceable.

If any leaks, odors, or deformities are noticed in the structure housing the battery, immediately discontinue use and dispose of safely.

Do not expose the device to water or otherwise allow the device to get wet.

KEEP OUT OF REACH OF CHILDREN AND PETS. For outdoor use as an insect repellent only. Do not use indoors, in tents or any enclosed area. Do not touch while the device is in use. Do not insert anything other than Thermacell® refill into the device. Place device on a flat, stable surface, facing upward. Do not cover with any material while in use. Clean with a damp cloth only when the device inactive. Wash hands after use.

Toxic to aquatic life, DO NOT allow chemical, containers, refills or vapour to get into drains, sewers, streams or ponds. Toxic to bees. However, the use of this product as directed is not expected to have adverse effects on bees.

STORAGE AND DISPOSAL

Store in the closed, original container in a cool, dry place out of reach of children. Do not store in direct sunlight. Store unused refills in original packaging in a cool, dry place inaccessible to children and pets. Wrap used refill and place in garbage. Do not incinerate refill. Do not discard this product as household

waste. The Thermacell contains Lithium-Ion batteries. Please safely dispose of the product.

SAFETY DIRECTIONS

Harmful if inhaled. May irritate the eyes and skin. Avoid contact with eyes and skin. Do not inhale vapour. Wash hands after use.

FIRST AID

If poisoning occurs, contact a doctor or Poisons Information Centre, Phone Australia 131 126: New Zealand 0800 764766. If swallowed, do NOT induce vomiting.

For further product information contact Mayo Hardware 1300 360 211

APVMA Approval No.: 89453/124940

USE ONLY Thermacell Zone Refills. Thermacell will not be responsible for damage, injury or poor product performance caused by use of any other refills or unapproved replacement parts in this Thermacell device.